

AC CIRCUITS

Sinusoidal Waveforms:	$v(t) = V_{\max} \cos(\omega t + \alpha)$ Volts	$i(t) = I_{\max} \cos(\omega t + \beta)$ Amps
Phasors	$V = V_{\text{rms}} \angle \alpha$ Volts	$I = I_{\text{rms}} \angle \beta$ Amps
Angular Frequency, ω	$\omega = 2\pi f$ Radians/Second $\omega = 377$ Rad/sec in North America $\omega = 314$ Rad/sec where 50 Hz is std.	In North America: $f = 60$ Hz Elsewhere, usually: $f = 50$ Hz
Effective Value (RMS)	$V_{\text{rms}} = V_{\max} / \sqrt{2}$ Volts	$I_{\text{rms}} = I_{\max} / \sqrt{2}$ Amps
Ohm's Law	for DC Circuits: $V = IR$	AC: $V = IZ$; Where V, I and Z are complex phasors.
Complex Impedance, Z	$Z = R + jX$ $Z = Z \angle \theta$	$jX_L = j\omega L$ (L in Henries) $-jX_C = 1/j\omega C$ (C in Farads)
Complex Loads in Parallel	$Z_{\text{eq}} = \frac{1}{\frac{1}{Z_1} + \frac{1}{Z_2}} = \frac{Z_1 Z_2}{Z_1 + Z_2}$	

AC POWER

Instantaneous Power, p(t)	$p(t) = v(t) i(t)$ Volt-Amperes	Product of sinusoidal signals
Real Power (Effective Power)	$P = V_{\text{rms}} I_{\text{rms}} \cos \theta$ Watts	V_{rms} and I_{rms} are the <u>magnitudes</u> of the voltage and current phasors
Power Factor, pf	$\text{pf} = \cos \theta$ (no units) Either expressed as Per Unit or as Percent.	$\theta = \text{Angle}(V) - \text{Angle}(I)$ $= \tan^{-1}(X/R)$ $= \tan^{-1}(Q/P)$ $= \text{Angle}(Z)$
Power Angle, θ	If θ is Positive: pf is lagging, I lags V, and Q is Inductive	If θ is Negative: pf is leading, I leads V, and Q is Capacitive
Reactive Power, Q	$Q = V_{\text{rms}} I_{\text{rms}} \sin \theta$ VARs	Volt-Amperes – Reactive (VAR)
Apparent Power, S 	$ S = V I $ Volt-Amperes	Product of Voltage and Current magnitudes
Complex Power, S	$S = V I^*$ or $S = P + jQ$	Product of Voltage Phasor and the complex conjugate of the Current Phasor: $I^* = I_{\text{rms}} \angle -\theta_I$

3-PHASE AC CIRCUITS and POWER:

Note: Always assume a given Voltage is Line Voltage, unless otherwise specified.

Phase Voltage, V_{Phase}	$V_{\text{Phase}} = V_{L-N}$ (Phase Voltage is often called the Line-to-Neutral Voltage)	In a WYE system. Phase Voltage is the voltage of a phase with respect to the neutral point of the WYE.
Line Voltage, V_{Line}	$V_{\text{Line}} = V_{L-L}$ (Line Voltage is often called the Line-to-Line Voltage)	In a WYE or a DELTA system the Line Voltage is measured at one phase with respect to another phase.
WYE Source or Load:	$V_{\text{Line}} = \sqrt{3} V_{\text{Phase}} \angle +30^\circ$	$I_{\text{Line}} = I_{\text{Phase}}$
DELTA Source or Load:	$V_{\text{Line}} = V_{\text{Phase}}$	$I_{\text{Line}} = \sqrt{3} I_{\text{Phase}} \angle -30^\circ$
3-Phase Power, $P_{3\phi}$	$P_{3\phi} = \sqrt{3} V_{\text{Line}} I_{\text{Line}} \cos \theta$ Watts	$Q_{3\phi} = \sqrt{3} V_{\text{Line}} I_{\text{Line}} \sin \theta$ VARs
3-Phase Apparent Power, $S_{3\phi}$	$ S_{3\phi} = \sqrt{3} V_{\text{Line}} I_{\text{Line}} $ Volt-Amperes	